

OLFA®

THE ORIGINATOR SINCE 1956

Disposal Case


plus

Auto-Lock Cutter



The answer for users who

**“Are afraid to snap off blades,” or
“Have trouble disposing of used blades.”**




DA-1

The Disposal Case can be easily detached from the cutter, and easily and safely used to snap off blades. Users enjoy enhanced safety while always working with a sharp blade no matter where they are. Applicable with a wide range of jobs and both left-handed and right-handed users.



DL-1

Heavy-Duty Cutter with Detachable Disposal Case




This 18mm Auto-Lock Cutter comes with a detachable Disposal Case that users easily pop off for use.

More Easily Snap Off Blades




DA-1 Compact Auto-Lock Cutter with a Detachable Disposal Case!

OLFA has incorporated a detachable Disposal Case that makes it easier and safer to snap off and dispose of used blades into a small Auto-Lock Cutter used widely at home and the office. It greatly reduces the hassles of snapping off blades and enhances to a maximum the advantages of the replaceable blade system that gives users the sharpness they need at all times. This easy-to-use 9mm Auto-Lock Cutter with easy handy blade disposal can be used by both left-handed and right-handed users.




How to detach

Pull the "PULL UP" tab in the direction of the arrows to detach the Disposal Case from the cutter.



How to attach

Insert the tip of the Disposal Case into the backside of the cutter and press the "PULL UP" tab back down.




How to snap off blades *Use caution when snapping off blades.

Open the cap of the Disposal Case.

Insert the blade up to the segment line.

Bend the blade so that the segment line snaps to the outside.



The segment line is on the top face of the cutter blade. Bend the blade so that it arches and breaks at the segment line.

When filled with used blades




The Disposal Case can hold about 2 strips of blades. Open the Disposal Case carefully so that collected blades do not scatter. Dispose of used blades as directed by local waste codes.

SPARE BLADES

MODEL/MODÈLE

AB



MODEL/MODÈLE

ABB




Ultra sharp blades / Lames plus coupantes



How to replace blades

*Use caution when replacing blades.



How to detach the slider

Hold the cutter as shown at right and carefully push the slider off with your thumb.



MODEL	PACKAGE	BARCODE	INNER BOX	CARTON
DA-1	Blister Packed CARD SIZE: 80 x 220 mm	0 915111 90018 7	6 pcs. 200 91511 90018 1	240 pcs.[6x40] 600 91511 90018 9

Heavy-Duty model available too



This 18mm Auto-Lock Cutter with Detachable Disposal Case is for heavy-duty jobs. It, too, is designed to enhance safety.

MODEL	PACKAGE	BARCODE	INNER BOX	CARTON
DL-1	Blister Packed CARD SIZE: 95 x 220 mm	0 915111 20051 5	6 pcs. 200 91511 20051 9	120 pcs.[6x20] 600 91511 20051 7

! WARNING !

1. OLFA BLADES are extremely sharp! Handle with care.
2. Dispose of used blade in a safe manner.
3. Safety goggles should be worn when using.
4. Keep out of the reach of children.

URL <http://www.olfa.com>

MANUFACTURED BY OLFA CORPORATION, OSAKA 537-0021, JAPAN

Entire contents copyright OLFA CORPORATION All rights reserved.

PRINTED IN JAPAN 2010 December - DS